

Contactless “Mifare TestJob” Setup Instructions

1. Register the “MifareContactlessDemo” smart card application. (See Help Top “Add Applications” for procedure. Note that .DLL and .MFT file must reside in the same directory, whether on CD-ROM, hard-drive, network. etc. when registering the application.
2. Copy the file labeled ‘MifareDemoInput.txt’ to the same directory as the SCPM program file “ObjectCommunicator.EXE” is located. For SCPM v3.1, this directory is by default
C:\Program Files\Datacard\SCPM\BIN\